



Omaker M4 Wrist Strap Replacement

This guide will show how to attach a wrist strap to the Omaker M4 Speaker.

Written By: Andrew Entwistle



Step 1 — Wrist Strap



- Locate the designated attachment spot on the device. Feed the thin string loop under the plastic bridge through to the other side.

Step 2



- Pull the end of the loop through the device as far as possible.

Step 3



- Feed the end of the strap through the loop. Pull the strap tight until it is secure.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 07:21:04 PM.